

groov▶▶e

GV-BT1100 Zen



wireless |
AUDIO
PLAYBACK | wired

Zen

Wireless Headphones
with Active Noise
Cancelling

 Bluetooth®



30 Day Right To Return

We do not envisage any problems occurring with your Groov-e GV-BT1100 Zen Wireless Active Noise Cancelling Headphones. However, for your peace of mind, should any fault occur, please return it within 30 days to your retailer with proof of purchase for an exchange or refund.



12 Month Guarantee

This product is guaranteed for twelve months. Please retain your receipt as this will be required as proof of purchase in the event that the device does not perform as expected then please contact your original point of purchase, should you require further assistance then please contact us.



Extended Warranty

Please register your product within 30 days from date of purchase

www.groov-e.co.uk/warranty.

Proof of purchase required.



Contact Us

Reach out to us at **info@groov-e.co.uk** or visit **www.groov-e.co.uk**

“Congratulations on your purchase and **Thank You** for choosing the groov-e **GV-BT1100 Zen** Wireless Active Noise Cancelling Headphones. Please read the guide carefully before using”.

CAUTION

1. When not in use for a long period of time please turn off the headphones and store carefully to avoid any damage.
2. In order to prolong the battery life, please charge every 6 months.
3. Please charge the headphones first if it has been left unused for a long time.
4. The battery in the headphones is original and please do not attempt to change it yourself.
5. Please keep the headphones in a dry place.
6. Please keep away from temperatures in excess of 60 C to avoid battery blast accident.
7. Please don't bend or twist the headphones bracket to avoid deformation.
8. Please do not remove the ear-cushions.
9. Do not play at high volumes for long periods at a time. to avoid potential hearing damage.
10. Do not use the headphones in a dangerous place or whilst driving.

OVERVIEW

Included:


Bluetooth Active Noise Cancelling Headphones x1

Manual x1

3.5m Audio Cable x1

Micro USB Charging Cable x1

Pouch x1






CHARGE THE BATTERY

The headphones come with a Micro USB cable that can be connected to your computer or other device made for charging.

Plug the Micro USB end of the included USB cable into the Micro USB port under the right ear-cap of the headphones.

Plug the other end into a USB port on your computer or other devices made for USB charging. The indicator light will be red while charging.



Once fully charged the indicator light will turn off. Charging time is about 2.5 hours on an empty battery.



ACTIVE NOISE CANCELLING ON

Short Press the ANC Button for 1 second.



A green LED light will turn on. The ANC function is available in both Wired and Wireless mode.



ACTIVE NOISE CANCELLING OFF


To switch off, press the ANC Button for 1 second.

The green LED light will turn off.



SWITCH ON BLUETOOTH

To switch on, press and hold the MFB for 3-6 seconds.



The blue light comes on and the headphones enter Bluetooth searching mode.



SWITCH OFF BLUETOOTH

To switch off, press and hold the MFB for 3-6 seconds.



Until the light goes off.





PAIRING

Ensure that your phone or Bluetooth device you wish to pair is switched on.

To pair the headphones if it has not been previously paired with a device, firstly switch on the headphones using the MFB button.


The headphones enter pairing mode, the LED indicator light will start to flash blue and red alternately.




NOTE: To pair the headphones with a new device if it has previously been paired, ensure that the original paired device is switched off.



4. *Activate the Bluetooth feature on your phone or Bluetooth device and set to search.*




5. *Select "GV-BT1100" from the list of found devices on your phone or Bluetooth device.*




6. *When successfully paired the blue light remains lit.*

ADJUST THE VOLUME

Turn the volume up or down by a long press on the volume +/- key during a call or while listening to music.



When the volume reaches maximum or minimum levels there is a warning tone!



APPLICATION

"GV-BT1100" can make and receive calls hands-free with your compatible mobile phone and listen to music from a compatible Bluetooth device, but they should be within 10 meters (33 feet) of each other. The headphones are compliant with Bluetooth 5.0 and supports the following profiles: HSP, HFP, A2DP and AVRCP.

CALLS

To make a call, use your mobile phone in the normal way when the headphones are connected to it. When a phone call comes in, quickly press the MFB to answer it, or press and hold for about 1.5 seconds to reject the call. During a call, short press the MFB to end it.

VOICE ASSISTANT

To use the Siri/Google function quickly press the MFB twice to activate Siri/Google on your phone. This function is based on your phone supporting Siri/Google.

LISTEN TO MUSIC

To listen to music, connect the headphones to your phone or compatible Bluetooth device that supports the A2DP Bluetooth profile. The available music functions depend on your Bluetooth device.

If you receive or make a call while listening to music, the music is paused until the call ends.

To play a song, select it from your phone or compatible Bluetooth device and press the Play/Pause key on the headphones.

To pause or resume playing a song, press the Play/Pause key.

To select the next song during playback, short press the volume up key.

To select the previous song, short press the volume down key.


To increase the volume, press and hold the volume up key, there will be a beep tone when reaching the maximum volume level.

To decrease the volume, press and hold the volume down key. (there will be a beep tone when reaching the minimum volume level).


DISCONNECT THE HEADPHONES

To disconnect the headphones from your device, switch off the headphones, ensuring you also switch off the ANC if activated.


Or disconnect it in the Bluetooth menu of your device.



RECONNECT THE HEADPHONES



To connect the headphones to the phone or Bluetooth device that you have last used it with, switch on the headphones.



Or make the connection in the Bluetooth menu on your device.


If the headphones have previously paired with another device, it will automatically connect with that device, if the device is powered on and within connecting range. If not, the headphones will enter standby mode and the blue and red lights will continue to flash. When in Bluetooth searching mode, the headset will switch off automatically in 5 minutes, if it does not connect.

PASSIVE MODE

You can use the "GV-BT100" as a wired headphone to save batteries.

Simply connect one end of the 3.5mm audio cable to the bottom of the left ear-cup and the other end to your phone or audio device

Inserting the 3.5m audio cable will disable the wireless functionality, so previous/next track, volume and phone call functions will be controlled on your device.



NOTE: Please remember to switch off the ANC if activated when the headphones are not in use.

LOW BATTERY WARNING There will be an audible warning beep every 5 minutes.

POWER-OFF AT LOW BATTERY CONDITION The headphones will switch off automatically when the battery power drops below a certain level.

SPECIFICATIONS:

Bluetooth version 5.0
Bluetooth profiles: HSP, HFP, A2DP and AVRCP
Wireless range: 10M (open area)
Battery: Lithium battery 250mAh
Music playing time upto 10 hours
Charging time: 2.5 hours
Standby time: 200 hours
Driver unit: 40mm neodymium
Impedance: 32 ohms
Speaker frequency: 20-20KHz
Headphone Sensitivity (ANC off): 95dB+/-3dB
Headphone Sensitivity (ANC on): 104dB+/-3dB
Noise Reduction : 21dB ~ 24dB
Microphone sensitivity: -42dB +/- 3dB
Supports hands-free conversation
LED indicator

FEATURES:

- 40mm neodymium drivers for premium sound
- ANC (Active Noise Cancelling) technology blocks out external noise
- Bluetooth or Coded - both options for you to enjoy!
 - 10 hours wireless music playback (Bluetooth)
 - 3.5mm headphone jack for corded audio playback (non-Bluetooth)
- Voice assistant enabled
- Super bass
- Soft, on-ear cushions for long listening comfort
- Swivel ear cups
- Rechargeable battery
- Built-in mic for hands-free calls
- Micro-USB charging cable (included)
- Removable audio cable (included)
- Pouch (included)



Bluetooth Connectivity



Active Noise Cancelling (ANC)



Wireless Audio Playback



Super Bass



Voice Assistant



Soft Ear Pads



Hands-Free Microphone



Removable Audio Cable

BATTERY REMOVAL/DISPOSAL

This product contains batteries and should not be treated as normal household waste and should be recycled. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk Batteries contain substances that may be harmful to the environment and human health. Keep out of the reach of children and seek immediate medical help if swallowed.

Never throw batteries into a fire or attempt to open the outer casing. Should your product develop a fault and your battery needs replacing for further advice on how to safely remove your battery please visit our website at www.groov-e.co.uk

Environment Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or retailer for recycling advice.



GUARANTEE

Subject to the conditions stated below, Groov-e guarantees this equipment against defects in workmanship or materials of its mechanical and electronic component parts (excluding styling, battery cells, magnetic tapes, re-chargeable batteries, user removeable memory devices, with the exception where the battery is inbuilt into the product) for a period of one year from the date of purchase. This product will be repaired or if necessary replaced free of charge if it has been proven to be defective within the one year warranty period.

1) *Claims under this guarantee should be made through the authorised dealer/retailer from whom the equipment was purchased. If this is not possible, please contact Groov-e directly.*

2) *This guarantee is only valid when the equipment is purchased and retained within the United Kingdom and a valid proof of purchase has been provided.*

3) This Guarantee Excludes:

(i) *All damage caused through accident, misuse, wear and tear, neglect, installation and/or use in a manner inconsistent with technical and safety standards.*

(ii) *Alterations or adjustments made to equipment*

(iii) *Loss of data resultant from malfunction of hard drive or other storage device*

(iv) *Damage caused to any third party device as a result of using the product.*

4) *No liability under this guarantee shall be incurred:*

(i) *In respect of damage or loss occurring during transit to or from the purchaser*

(ii) *Where the serial number plate of the equipment has been removed or altered in any way.*

5) Groov-e shall not be liable for consequential damage, loss or injury arising from or in connection with the equipment, excepting only that nothing in this condition shall or shall be construed so as to exclude or restrict liability for negligence.

6) The cost of carriage to and from Groov-e shall be borne by the purchaser.

7) This guarantee is personal to the original purchaser and is not transferable.

8) If the equipment, in respect of which a claim hereunder is made, is found on examination to comply with the published specifications, a test fee may be incurred.

This guarantee is in addition to and does not in any way affect any statutory or other right of consumer purchasers, including those rights in relation to sections 13 to 15 of the Sale of Goods Act 1979, the Sale and Supply of Goods to Consumer Regulations 2002, The Consumer Rights Act 2015 or the Sale of Goods and Supply of Services Act 1980 (for ROI).

DECLARATION OF CONFORMANCE

Groov-e hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive 2014/53/EU. The complete declaration of conformity can be requested from us at:

groov»e

Unit J

Braintree Industrial Estate

Braintree Road

Ruislip

Middlesex

HA4 0EJ UK

www.groov-e.co.uk

Email: info@groov-e.co.uk

Telephone: 020 8839 0978

Authorised EU Representative

Rashmian EU Ltd

Robwyn House

Suite 3E

Corrintra

Castleblayney

Co. Monaghan

Ireland

Register your purchase for extended warranty

www.groov-e.co.uk/warranty

MADE IN CHINA