

groov▶▶**e**

GV-BT700 ULTRA

BLUETOOTH HEADPHONES



USER MANUAL

wireless / AUDIO
PLAYBACK **wired**

ULTRA
Wireless Headphones
with Powerful Sound

 **Bluetooth®**



30 Day Right To Return

We do not envisage any problems occurring with your Groov-e GVB700 Ultra Wireless Headphones. However, for your peace of mind, should any fault occur, please return it within 30 days to your retailer with proof of purchase for an exchange or refund.



12 Month Guarantee

This product is guaranteed for twelve months. Please retain your receipt as this will be required as proof of purchase in the event that the device does not perform as expected then please contact your original point of purchase, should you require further assistance then please contact us.



Contact Us

*Reach out to us at **info@groov-e.co.uk** or visit **www.groov-e.co.uk***

"Congratulations on your purchase and **Thank You** for choosing the **Groov-e GVB700 Ultra Bluetooth Headphones**
Please read the guide carefully before using".

CAUTION

- 1.** When not in use for a long period of time please turn off the headphones and store carefully to avoid any damage.
- 2.** In order to prolong the battery life, please charge every 6 months.
- 3.** Please charge the headphones first if it has been left unused for a long time.
- 4.** The battery in the headphones is original and please do not attempt to change it yourself.
- 5.** Please keep the headphones in a dry place.
- 6.** Please keep away from temperatures in excess of 60 C to avoid battery blast accident.
- 7.** Please don't bend or twist the headphones bracket to avoid deformation.
- 8.** Please do not remove the ear-cushions.
- 9.** Do not play at high volumes for long periods at a time. to avoid potential hearing damage.
- 10.** Do not use the headphones in a dangerous place or whilst driving.

OVERVIEW


Box Contents:


Bluetooth Headphones *1pc

3.5mm Audio Cable *1pc

Micro USB Cable *1pc

User Manual *1pc





OPERATION

Before using the headphones, you must charge the battery and pair the headphones with a compatible device.

CHARGING

The pack contains a Micro USB cable that can be connected to your computer or other device made for USB charging. Plug the Micro USB end of the included USB cable into the Micro USB port on the right ear cup of the headphones. Plug the other end into a USB port on your computer or other devices made for USB charging. The indicator light will be red while charging. Once fully charged, the indicator light will turn off. Charge time is 2.5 hours on an empty battery. The fully charged battery has power for up to 10 hours talk/music time (and up to 200 hours standby time).

Note: The headphones have a built-in lithium battery. Please fully charge for at least 4 hours before initial use.

POWER ON

To switch on, press and hold the Power button for about 2 seconds. The blue LED indicator light is briefly displayed. When the headphones are connected to a device and are ready for use, the blue LED indicator stays illuminated. When the headphones enter the pairing mode, the indicator light will flash quickly.

POWER OFF

To switch off, press and hold the Power button for about 3 seconds. The red LED indicator light is briefly displayed. If the headphones are not connected to a device within 3 minutes, they will switch off automatically.

OPERATION

PAIRING

1. Ensure that your phone or Bluetooth enabled device is switched on.
2. To pair the headphones if they have not been previously paired with a device, switch on the headphones and hold the power button down until the blue and red lights blink alternately. You may have to hold the button down for more than 5 seconds until the blue and red lights flash. The headphones have now entered pairing mode.
3. Activate the Bluetooth function on your phone or Bluetooth device and set it to search for available Bluetooth devices.
4. Select "GV-BT700" from the list of available devices on your phone or Bluetooth device.
5. When successfully connected the LED indicator stays illuminated.

Note: If the headphones have been previously paired with another device they will automatically connect with the device if the devices power is on and within connecting range, if not, the headphones will enter standby mode with a continuous blue light.

ADJUST THE VOLUME

To adjust the volume, press and hold the volume key up or down during a call or while listening to music.

APPLICATION

GV-BT700 can make and receive calls hands-free with your compatible mobile phone and listen to music from a compatible Bluetooth device, but they should be within 10 meters (33 feet) of each other.

The headphones are compliant with the Bluetooth specification 4.0 and support the following profiles: headphone Profile (HSP) V1.6, Hands-Free Profile (HFP) V1.5, Advanced Audio Distribution Profile (a2DP) V1.0, and Audio Video Remote Control Profile (AVRCP) V 1.4, Input rating 5V DC, 0.5A.

CALLS

To make a call, use the buttons on your mobile device.

DISCONNECT THE HEADPHONES

To disconnect the headphones from your device, switch off the headphones, or disconnect it in the Bluetooth menu of your device.

RECONNECT THE HEADPHONES

To connect the headphones to the phone or Bluetooth device that you have last used it with, switch on the headphones, or make the connection in the Bluetooth menu on your device.

OPERATION

LISTEN TO MUSIC

To listen to music, connect the headphones to a phone or compatible Bluetooth device that supports A2DP Bluetooth profile. The available music functions depends on your Bluetooth device. If you receive or make a call while listening to music, the music is paused until the call ends. To play a song, select a track on your music player and press the Play/Pause button on the headphones. To select the next song during playback, press the Next Track button quickly. To select previous track press the Previous Track button quickly.

PASSIVE MODE

You can use the GV-BT700 as a wired headphone to save batteries. Connect one end of the included audio cable to the bottom of the right ear cup and the other end to your audio player's 3.5mm jack.

Note: Inserting the audio cable disables the wireless functionality.

SPECIFICATIONS

Bluetooth version: 4.0

Bluetooth profiles: HFP, A2DP and AVRCP

Wireless range: 10M (open area)

Battery: Lithium Ion battery 3.7V 400mAh

Music playing time: 12-15 hours (battery saturation)

Charging time: 3 hours

Standby time: More than 200 hours

Driver unit: 40mm

Impedance: 32 ohms

Speaker frequency: 20-20KHz

Speaker sensitivity: 102dB +/- 3dB

Frequency: 2.4GHz - 2.480GHz



Bluetooth
Connectivity



Active
Noise



Wireless
Audio



Super
Bass



Comfortable
Fit



Hands-Free
Microphone



Swivel
Ear Cups



Removable
Audio Cable

Battery Removal/Disposal

This product contains batteries and should not be treated as normal household waste and should be recycled. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

Batteries contain substances that may be harmful to the environment and human health. Keep out of the reach of children and seek immediate medical help if swallowed.

Never throw batteries into a fire or attempt to open the outer casing.

Should your product develop a fault and your battery needs replacing for further advice on how to safely remove your battery please visit our website at www.groov-e.co.uk

Environment Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



GUARANTEE

Subject to the conditions stated below, Groov-e guarantees this equipment against defects in workmanship or materials of its mechanical and electronic component parts (excluding styling, battery cells, magnetic tapes, re-chargeable batteries, user removeable memory devices) for a period of one year from the date of purchase. This product will be repaired or if necessary replaced free of charge if it has been proven to be defective within the one year warranty period.

Conditions

- 1)** Claims under this guarantee should be made through the authorised dealer/retailer from whom the equipment was purchased. If this is not possible, please contact Groov-e directly.
- 2)** This guarantee is only valid when the equipment is purchased within the United Kingdom and a valid proof of purchase has been provided.
- 3)** This guarantee excludes:
 - (i)** All damage caused through accident, misuse, wear and tear, neglect, installation and/or use in a manner inconsistent with technical and safety standards in a country other than the country of purchase
 - (ii)** Alterations or adjustments made to equipment
 - (iii)** Loss of data resultant from malfunction of hard drive or other storage device
 - (iv)** Damage caused to any third party device as a result of using the product
- 4)** No liability under this guarantee shall be incurred:
 - (i)** In respect of damage or loss occurring during transit to or from the purchaser
 - (ii)** Where the serial number plate of the equipment has been removed or altered in any way.
- 5)** Groov-e shall not be liable for consequential damage, loss or injury arising from or in connection with the equipment, excepting only that nothing in this condition shall or shall be construed so as to exclude or restrict liability for negligence.
- 6)** The cost of carriage to and from Groov-e shall be borne by the purchaser.
- 7)** This guarantee is personal to the original purchaser and is not transferable
- 8)** If the equipment, in respect of which a claim hereunder is made, is found on examination to comply with the published specifications, a test fee may be incurred.

This guarantee is in addition to and does not in any way affect any statutory or other right of consumer purchasers, including those rights in relation to sections 13 to 15 of the Sale of Goods Act 1979, the Sale and Supply of Goods to Consumer Regulations 2002, The Consumer Rights Act 2015 or the Sale of Goods and Supply of Services Act 1980 (for ROI).

DECLARATION OF CONFORMANCE

Groov-e hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive 2014/53/EU. The complete declaration of conformity can be requested from us at

groov»e

Unit J, Braintree Industrial Estate

Braintree Road

Ruislip

HA4 0EJ

Tel: +44 (0)20 8845 7704

info@groov-e.co.uk

www.groov-e.co.uk