

groov▶▶**e**

GV-TW08 JazzBuds
True Wireless Earphones



Easy Start Up Guide

*True Wireless
Earphones with
Portable
Charging Case*

JazzBuds





30 Day Right To Return

We do not envisage any problems occurring with your groov-e GV-TW08 True Wireless Earphones. However, for your peace of mind, should any fault occur, please return it within 30 days to your retailer with your proof of purchase for an exchange or refund.



12 Month Guarantee

This product is guaranteed for twelve months. Please retain your receipt as this will be required as proof of purchase. In the event that the device does not perform as expected then please contact your original point of purchase, should you require further assistance then please contact us.



Extended Warranty

Please register your product within 30 days from date of purchase www.groov-e.co.uk/warranty. Proof of purchase required.




Contact Us

Reach out to us at info@groov-e.co.uk or visit www.groov-e.co.uk


PRODUCT OVERVIEW

Packaging Contents:


1. GV-TW08 Earphones *1 pair
2. TYPE-C Cable *1 pc
3. Charging Case *1 pc



Charging Case X1




Bluetooth Earphones X1



USB-C Charging Cable X1

BRIEF INTRODUCTION



"Congratulations on your purchase and **Thank You** for choosing the groov-e GV-TW08 JazzBuds True Wireless Stereo Earphones. Please read the guide carefully before using".

Caution

- 1.** When not in use for a long period of time please turn off the Earphones and store carefully to avoid any damage.
- 2.** In order to prolong the battery life, please charge every 1 month when not in use for a long period of time.
- 3.** Please charge the Earphones first if they have been left unused for a long time.
- 4.** The batteries in the Earphones and Charging case are original and please do not attempt to change them yourself.
- 5.** Please keep the Earphones and Charge Case in a dry place.
- 6.** Please keep away from high heat sources to avoid battery blast accidents.
- 7.** Do not play at high volumes for long periods at a time to avoid potential hearing damage.
- 8.** Do not use the Earphones in a dangerous place or whilst driving.

Charging


There is a built-in rechargeable battery inside both Earphones and the charging case, which must not be disassembled. Ensure you have removed the blue charging port protectors from both earphones before the initial charge.

Basic operations

1. To switch the Earphones on, press the **MFB** for approximately 2 seconds. You will hear a voice prompt confirming **"Power On"**. To switch the Earphones off, press the **MFB** for approximately 5 seconds. You will hear a voice prompt confirming **"Power Off"**

OR

2. To switch the Earphones on, take out the earphones from the charging case, L & R earphone will pair with each other automatically. You will hear a **"beep"** sound. To switch the Earphones off, place the earphones into the charging case.



3. Whilst receiving a phone call, short press the **MFB** to answer the call, and short press the MFB again to hang up. To reject an incoming call, press the **MFB** for 2 seconds.



4. If you wish to open voice assistant (Siri or Google) whilst in standby mode, press the **MFB** for 2 seconds until you hear a **"beep"** sound. This will open your device's default assistant without having to retrieve or unlock it, which will then listen and respond to any voice command. Ensure that a voice assistant is installed on your device.

5. To play/pause music, **tap** the **MFB** once.
To play next track (Right Earphone) quickly **double tap** the **MFB**.
To turn Volume up (Right Earphone) quickly **triple tap** the **MFB**.
To play previous track (Left Earphone) quickly **double tap** the **MFB**.
To turn Volume down (Left Earphone) quickly **triple tap** the **MFB**.


Please Note: In stereo mode if you switch off one Earphone it will also power off the second.

CHARGING THE CASE


To charge the case plug the USB charging cable supplied into the charging port.





Connect it to DC5.0V USB port or a suitable USB charging device.



The white led display light flashes while charging.





The white led display light will remain at 100 when charging completed..



You can charge the case and carry it with you as a storage case for your earphones.

HOW TO REMOVE THE EARPHONE FROM THE CHARGING CASE



Open the charging case's cover to about 90 degrees. Then remove both Earphones vertically.



CHARGING THE EARPHONES


Place the earphones into the charging case.

The led light remain RED on both Earphones indicating that they are charging.



The RED light will switch off when the Earphones are fully charged,

To alert you to the fact that your Earphones require charging you will hear a voice prompt indicating **"please charge"**






The number represented in the display is the current capacity of the charging case which will also stop charging automatically when fully charged.



Please note the earbuds will switch off automatically whilst in the charging case.



HOW TO PAIR

Remove both Earphones from the case.



Providing your device/phone is switched on and within pairing distance your earphones will autoconnect to your device the next time you switch them on.


Turn on Bluetooth on your Bluetooth enabled device/phone and scan for "GV-TW08", select and pair with the Earphones.




***Please be sure to fully charge the GV-TW08, when you are using them for the first time.**

HOW TO PAIR A SINGLE EARPHONE


Remove one Earphone from the case.





The earphone will enter pairing mode automatically. The red and blue lights flash alternately to confirm you are in pairing mode.



Turn on Bluetooth on your Bluetooth enabled device and scan for "GV-TW08" and pair.



The volume Up and Next track selection is controlled by the paired earphone.



Note: Whilst in Mono mode the volume down and previous track selection is controlled via your Bluetooth device

FEATURES

Bluetooth connectivity

True Wireless Stereo (TWS)

Voice Assistant Enabled

Touch Control

Up to 4 hours music playback - and up to an additional 21 hours using the charging case

Music play/pause

Volume & track control

Clear sound with powerful bass

Comfortable fit

Ergonomic design

Rechargeable battery

Auto power on/off, Auto pairing

Built-in mic for hands-free calls

Answer/Reject incoming calls

Type-C USB charging cable (included)

Portable intelligent charging case with LED display (included)

SPECIFICATIONS (Earphones)

Bluetooth version 5.0

Bluetooth profiles: A2DP, AVRCP, HFP, HSP

Wireless range: 10M (open area)

Battery: 25mAH x 2

Music playing time up to 4 hours (1 charge)

Standby time: 100 hours

Speaker frequency: 20-20KHz

Speaker sensitivity: 107+/-3dB

LED indicator

SPECIFICATIONS (Charging Case)

Case recharge capacity: 400mAH

Charging time for case: 1.5 hours

LED display for battery charging



Bluetooth
Connectivity



Wireless
Audio Playback



Voice
Assistant



Touch
Control



Charging Case
Included

Battery Removal/Disposal

This product contains batteries and should not be treated as normal household waste and should be recycled. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

Batteries contain substances that may be harmful to the environment and human health. Keep out of the reach of children and seek immediate medical help if swallowed.

Never throw batteries into a fire or attempt to open the outer casing.

Should your product develop a fault and your battery needs replacing for further advice on how to safely remove your battery please visit our website at www.groov-e.co.uk

Environment Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist.

Check with you Local Authority or retailer for recycling advice.



Guarantee

Subject to the conditions stated below, Groov-e guarantees this equipment against defects in workmanship or materials of its mechanical and electronic component parts (excluding styling, battery cells, magnetic tapes, re-chargeable batteries, user removeable memory devices, with the exception where the battery is inbuilt into the product) for a period of one year from the date of purchase. This product will be repaired or if necessary replaced free of charge if it has been proven to be defective within the one year warranty period.

- 1)** Claims under this guarantee should be made through the authorised dealer/retailer from whom the equipment was purchased. If this is not possible, please contact Groov-e directly.
- 2)** This guarantee is only valid when the equipment is purchased and retained within the United Kingdom and a valid proof of purchase has been provided.
- 3) This Guarantee Excludes:**
 - (i)** All damage caused through accident, misuse, wear and tear, neglect, installation and/or use in a manner inconsistent with technical and safety standards.
 - (ii)** Alterations or adjustments made to equipment
 - (iii)** Loss of data resultant from malfunction of hard drive or other storage device
 - (iv)** Damage caused to any third party device as a result of using the product.
- 4) No liability under this guarantee shall be incurred:**
 - (i)** In respect of damage or loss occurring during transit to or from the purchaser
 - (ii)** Where the serial number plate of the equipment has been removed or altered in any way.
- 5)** Groov-e shall not be liable for consequential damage, loss or injury arising from or in connection with the equipment, excepting only that nothing in this condition shall or shall be construed so as to exclude or restrict liability for negligence.
- 6)** The cost of carriage to and from Groov-e shall be borne by the purchaser.
- 7)** This guarantee is personal to the original purchaser and is not transferable.
- 8)** If the equipment, in respect of which a claim hereunder is made, is found on examination to comply with the published specifications, a test fee may be incurred.

This guarantee is in addition to and does not in any way affect any statutory or other right of consumer purchasers, including those rights in relation to sections 13 to 15 of the Sale of Goods Act 1979, the Sale and Supply of Goods to Consumer Regulations 2002, The Consumer Rights Act 2015 or the Sale of Goods and Supply of Services Act 1980 (for ROI).

DECLARATION OF CONFORMANCE

Groov-e hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive 2014/53/EU. The complete declaration of conformity can be requested from us at:

Please contact the (UK) office for all product enquires

groov»e

Unit J
Braintree Industrial Estate
Braintree Road
Ruislip
Middlesex
HA4 0EJ (UK)

www.groov-e.co.uk

Email: info@groov-e.co.uk

Telephone: +44 (0)20 8839 0978

Authorised EU Representative

Rashmian EU Ltd
Robwyn House
Suite 3E
Corrintra
Castleblayney
Co. Monaghan
Ireland

Register your purchase for extended warranty

www.groov-e.co.uk/warranty